

BUSINESS ADDRESS:
207 N. Saginaw St.
Byron, MI 8418
(810) 266-6526
barnwood@timelesslumber.com



WAREHOUSE ADDRESS:
119 N. Saginaw St.
Byron MI 48418
DATE: 10/26/2024
www.timelesslumber.com

To mount corbels

To mount corbels we figured 6" to 8" from the ends. 3/8" holes should be drilled level and straight at desired locations 3/4" down from where you want the bottom of the mantel to be located to a depth of almost 4" from face of 1/2" drywall to not come out the other side of wall. Be sure there is adequate structure for mounting bolts. For brick use 1/2" lead anchors and appropriate masonry bit. Install mounting bolts to the mark on bolt or 4" deep. Slide corbels partially on till washer and nut can start to be threaded on and tighten down to bring corbels tight to wall. Mantel is not marked in case a different face is desired and corbels can be reshaped with belt sander if changes are made to location. Construction adhesive can be used to glue mantel to corbels and wall after dry run is approved.

For stone installation you may want to fur out the mantel and corbels accordingly and get longer !0" anchor bolts from www.nutty.com part# HB121310.

We do our best to give good installation instructions here but every application is different and should be preformed by a skilled installer. You can give us a call with any questions to help you mount your reclaimed barn wood mantel for years of enjoyment.

Thank you,

